

A4VG HYDRAULIC PARTS



16

NO.	DESCRIPTION	PCS
1	CYLINDER BLOCK	1
2	PISTON SHOE	9
3	VALVE PLATE	1
4	RETAINER PLATE	1
5	BALL GUIDE	1
6	DRIVE SHAFT	1
7	SWASH PLATE	1
8	SADDLE BEARING & SEAT	2
9	BEARING	2
10	CHARGE PUMP	1
11	DISC SPRING	4
12	COIL SPRING	1
13	SPACER	2
14	SNAP RING	1
15	7 PIN	2
16	SEAL KIT	1