

HRR057 HYDRAULIC PARTS



HRR057 PUMP

NO.	DESCRIPTION	PCS
1	CYLINDER BLOCK	1
2	VALVE PLATE	1
3	PISTON SHOE	9
4	RETAINER PLATE	2
5	BALL GUIDE	1
6	DRIVE SHAFT	1
7	SWASH PLATE	1
8	TRUST PLATE	1
9	RETAINER	2
10	SADDLE BEARING	2